

NEFAB RackPak Hood Handling Instructions

PAGE 1/2











Four people needed Safety shoes needed No tools needed

SAFETY INSTRUCTIONS



Needed space:

- 1.5 m in front
- 2.0 m behind
- 1.0 m on both sides

SAFETY INSTRUCTIONS











Fully fold back opened latches

SAFETY INSTRUCTIONS



Never use front door as ramp!

A SAFETY INSTRUCTIONS



For removing and placing the hood, disregard labels.

HOOD REMOVAL STEP 1



Remove front door and put it aside. For details, see Folding instructions.

HOOD REMOVAL STEP 2



Stand at four corners of base

HOOD REMOVAL STEP 3



HOOD REMOVAL STEP 4




Carefully lift hood upwards using four lower handles

HOOD REMOVAL STEP 5



Slowly move hood behind base

Open all four lower latches **HOOD REMOVAL STEP 6**



Fold the rear flap underneath the hood and lower onto floor.



Do not transport the hood when removed from base



RackPak Hood Handling Instructions

PAGE 2/2



HOOD PLACEMENT STEP 1



Place base (with or without product on it) in front of hood

HOOD PLACEMENT STEP 2



Stand at four corners of hood

HOOD PLACEMENT STEP 3



Using four lower handles, carefully lift hood

HOOD PLACEMENT STEP 4



Position hood right above base

HOOD PLACEMENT STEP 5



Lower hood down onto profiles in base.



Ensure that profiles grab into each other over full length, and that front corners align.

HOOD PLACEMENT STEP 6



Close all four lower latches

HOOD PLACEMENT STEP 7



Place the front door. For details, see Setup instructions.