


# OPENING INSTRUCTIONS

## OPENING EXPAK WITH PINCERS



Step 1: Insert the Pincer "teeth" into the tongue slot in the profile. Pull to open up the profile tongue slot.



Step 2: Close the Pincer and bend the tongue upwards 180 degrees.



Step 3: Straighten tongue by pulling and sliding Pincer "teeth" upwards over the tongue.



Step 4: The tongue should be vertical and free of kinks, so that it does not catch on the profile slot when the lid is removed.